





# QUICK START GUIDE

## STANDARD DISPENSER:

*(Check that the dispenser is correctly configured for your jurisdictional rules.)*

1. Plug the dispenser line cord into the AC receptacle on the left side of the dispenser
2. Plug the other end of the cord into earth grounded, three-prong, AC outlet
3. Turn the power on with the switch on the left side of the dispenser.

When the dispenser powers on, the following screens will appear while it is booting. The first screen shows the firmware revision level and machine information. The second screen will appear momentarily while the two internal computers synchronize their information. With a successful boot, the dispenser will show the standard INSERT MONEY screen.



4. Open the main door and key in 9000# for the PIN. The main Service Menu will appear:



5. Open the electronics door to access the battery pack at the very top of the cabinet
6. Place the battery pack switch to the ON (I) position
7. Close the electronics door
8. Load the tickets
9. On the main Service Menu, select 4 for the Price followed with #key
10. Set the ticket prices for the columns and use M on the keypad to return to the main Service Menu
  - *If needed, more assistance to set prices is available in the user manual*
11. On the main Service Menu, select 5 for Time
12. Set the date/time and use # on the keypad to save the setting and return to the main Service menu
  - *If needed, more assistance to set time is available in the user manual*
13. Close the main door
14. The INSERT MONEY screen will appear
15. The dispenser is ready to accept money and dispense tickets

**BEFORE USING THE DISPENSER PLEASE READ THE FOLLOWING SECTIONS OF THE USER MANUAL CONCERNING USE OF THE DISABLE KEY, DISPENSER CONFIGURATION OPTIONS, PASSWORD SECURITY, CLEARING SESSION LOGS AND FINANCIALS.**